
GM0329 - 空槍不掛機使用說明 - EMPTY MAGAZINE NON-LOCKING USER GUIDE

1



2




·GM0329 可壓住彈匣掛機擺桿，使其無法抬起，從而實現空槍不掛機狀態，方便玩家進行各項測試。
GM0329 適用於 TM 與 GM 彈匣（新款 GM 彈匣自帶空槍不掛機功能）。
·GM0329 presses down the magazine bolt catch paddle to prevent it from lifting, achieving a no-last-round-hold-open state for easy testing.
GM0329 is compatible with TM and GM magazines. （New GM magazines come with a built-in no-last-round-hold-open function.）

3



示意圖 Cross-sectional schematic of the part



·為便於說明，以下將以GM彈匣作為示例進行說明。如圖3所示，先用手將掛機擺桿壓住，再將GM0329放入。
·For clarity, the following example uses GM magazines as a reference.
As shown in Figure 3, manually press down the bolt catch paddle first, then insert the GM0329 into position.

4



示意圖 Cross-sectional schematic of the part




·確保GM0329放入到位。
·Ensure the GM0329 is fully seated in place.

5



示意圖 Cross-sectional schematic of the part



·放開掛機擺桿，GM0329即安裝完成。
·Release the bolt catch paddle. The GM0329 installation is now complete.

GM



TM



·拆除 GM0329 同樣非常簡單：GM 彈匣只需按住掛機擺桿，再將 GM0329 倒出即可；TM 彈匣則需用手捏住或借助工具輕輕左右搖晃，以便順利取出。
·Removal of the GM0329 is equally simple: for GM magazines, just hold down the bolt catch paddle and tip the GM0329 out; for TM magazines, you'll need to grip it by hand or use a tool to gently wiggle it left and right for easier extraction.