

GM0329 - 空槍不掛機使用說明 - EMPTY MAGAZINE NON-LOCKING USER GUIDE

1



2



- GM0329 可壓住彈匣掛機擺桿，使其無法抬起，從而實現空槍不掛機狀態，方便玩家進行各項測試。
GM0329 適用於 TM 與 GM 彈匣（新款 GM 彈匣自帶空槍不掛機功能）。
- GM0329 presses down the magazine bolt catch paddle to prevent it from lifting, achieving a no-last-round-hold-open state for easy testing.
GM0329 is compatible with TM and GM magazines. (New GM magazines come with a built-in no-last-round-hold-open function.)

3



示意圖 Cross-sectional schematic of the part



- 為便於說明，以下將以GM彈匣作為示例進行說明。如圖3所示，先用手將掛機擺桿壓住，再將GM0329放入。
- For clarity, the following example uses GM magazines as a reference.
As shown in Figure 3, manually press down the bolt catch paddle first, then insert the GM0329 into position.

4



示意圖 Cross-sectional schematic of the part



- 確保GM0329放入到位。
- Ensure the GM0329 is fully seated in place.

5



示意圖 Cross-sectional schematic of the part




- 放開掛機擺桿，GM0329即安裝完成。
- Release the bolt catch paddle. The GM0329 installation is now complete.

GM



TM



- 拆除 GM0329 同樣非常簡單：GM 彈匣只需按住掛機擺桿，再將 GM0329 倒出即可；TM 彈匣則需用手捏住或借助工具輕輕左右搖晃，以便順利取出。
- Removal of the GM0329 is equally simple: for GM magazines, just hold down the bolt catch paddle and tip the GM0329 out; for TM magazines, you'll need to grip it by hand or use a tool to gently wiggle it left and right for easier extraction.